



BC1212

NO.	DESCRIPTION
1	JUMP STARTER SOCKET
2	LED
3	LED LENS
4	DISPLAY COVER
5	UP COVER
6	DOWN COVER
7	MIDDLE COVER
8	JUMP STARTER SOCKET COVER
9	BUTTON
10	PCB & USB ASSEMBLY
11	Li BATTERY
12	CHARGER
13	TERMINAL CLAMP

RU-ST20170605