



HM2500

NO.	DESCRIPTION	NO.	DESCRIPTION
1	FAN COVER	19	SCREW
2	SCREW	20	SCREW NUT
3	FAN	21	CRUSHING MACHINE HEAD
4	SCREW	22	PLASTIC CONNECTION
5	MOTOR AND COVER	23	CONTROL PLATE
6	BEARING 6204RS	24	HOPPER
7	ROTOR	25	SCREW
8	PIN	26	SCREW
9	GASKET	27	MESH
10	ROTOR NUT	28	BLADE
11	MOTOR	29	SEAL RING
12	MOTOR BODY	30	HEAD COVER
13	CAPACITOR BOX	31	GASKET
14	SCREW	32	SCREW
15	CAPACITOR	33	CORD & PLUG
16	BEARING 6203RS	34	THREAD DRAWING
17	NUT	35	SWITCH
18	MOTOR CONNECTION	999	MOTOR ASSEMBLY

RU-ST20160602

Sturm!
нас рекомендуют друзья

Sturm!
нас рекомендуют друзья