



ES9065

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BEARING COVER	30	SCREW
2	BEARING 608	31	GUARD PLATE
3	RETAINING RING	32	STEEL BALL
4	MIDDLE COVER	33	COLUMN PIN
5	SCREW	34	SCREW
6	BEARING 625	35	ROTOR
7	SMALL GEAR	36	INDUCTOR
8	GEAR SHAFT	37	BEARING 607
9	PAPER WASHER	38	BEARING BUSH
10	CIRCLIP	39	WIND GUARD
11	BIG GEAR	40	RUBBER PIN
12	CIRCLIP	41	STATOR
13	BEARING 6000	42	REAR COVER
14	FLAT KEY	43	CORD & PLUG
15	ECCENTRICITY SHAFT	44	CORD SLEEVE
16	CIRCLIP	45	SCREW
17	BEARING 609	46	CORD CLAMP
18	GEAR BOX	47	BRAND
19	SCREW	48	HOUSING
20	NEEDLE BEARING	49	CARBON BRUSH
21	CONNECTION ROD	50	BRUSH HOLDER
22	BUSH	51	TWIST SPRING
23	PISTON PIN	52	SWITCH KNOB
24	RECIPROCATING BAR	53	LINK POLE
25	BLADE CLAMP	54	SPRING
26	SCREW	55	SWITCH
27	BLADE BRACKET	56	SCREW
28	SCREW	57	CAPACITOR
29	SCREW		

RU60707-1